

FEATURES

Ripper is used to break the lower impermeable hard pan, which cannot be broken by normal cultivation operations. Successful ripping loosens and shatters compact soil layers by creating many cracks and fissures thus allowing roots to develop more freely and water to move down more rapidly. This rather inexpensive implement provides a simple and economical way to obtain good crop yields and profits.

SPECIFICATIONS

Model	FRIP1	FRIP2	FRIP3
Length (mm)	510	550	830
Width (mm)	660	1220	1520
Height (mm)		1060-1370	
Tyne (mm)		150x25	
No. Of Tynes	1	2	3
3 Point Linkage		CAT-11	
Accessories (optional)		Crumbler	
Crumbler (mm)		33.7 X 25 Round Pipe	
Crumbler Length (mm)	650	1220	1530
Weight Without Crumbler (kg)	68	195	280
Weight With Crumbler (kg)	150	245	430
Tractor Power Required (hp/kw)	40-55/30-41	60-75/44-55	80-85/59-63

